

WIRELESS REMOTE OPERATIONS



Serial Number Commands


-Press Buttons Simultaneously-



- The receiver will store up to 4 serial numbers. (Meaning a maximum of 4 different keyfobs)
- Once the 4 serial numbers have been loaded from 4 keyfobs, loading the serial number of an *additional* keyfob will cause a previously loaded keyfob's # to be removed from the list in the receiver's memory.

A High Frequency beep will confirm the newly added, or a previously added serial number. A Low Frequency beep indicates that the number did not take.
- Serial numbers can only be loaded or erased within the **first 10 seconds** after the receiver has been turned on.
- As a safety feature, the receiver will only respond to commands from keyfobs that have been loaded into its memory. (Max = 4 keyfobs)


Single Button Commands



Two Button Commands

-Press Both Buttons Simultaneously-



- When the receiver has power, the motors will also have power. However, the system will be in OFF mode.
- Pushing and holding the  button will turn the system ON & will cause the motors to turn.
- Speed settings are retained in memory when motors are OFF as long as the receiver has power.
 - When motors are turned back ON, the modified settings will take effect.
 - Steering will automatically return to center.